


Bullen Box Score Clock Instructions

GETTING THE CLOCK UP AND RUNNING


- Control panel is located in a black case inside the storage room (3rd locker on the lower right)
- Connect two black cables from the cabinet below the table to the two ports on the back of the control panel
- Plug in the power adapter between the control box and outlet below
- Plug in Yellow plug in cabinet below to the outlet below
- Plug in the hand toggle (on & off switch)
- Turn on Control Box (power switch on the right side of control)
- Control will ask “Start where you left off?” Enter NO
- “Operate Wireless?” – Enter NO
- Switch to Bright? – Enter YES
- The time and the direction it will count [0:00.0 DN] will be displayed, and the scoreboard(s) will turn on.

SETTING THE TIME

For 15:00 minute period, press....




Period



To start and stop the clock use the thumb switch on the handset

To change the score



To correct a score error



To silence the Auto Horn at the end of the period - Press HORN button

To set or disable auto horn - Press SET then HORN and select YES or No

Repeat for second period if scoreboard does not automatically reset to 15 minutes and period 2